EQUIPMENT TEST LIST CLEANING, RECONDITIONED APPEARANCE MISCELLANEOUS APPARATUS

		CONTENTS	PAG	Œ
22.	GENE	RAL		.1
	22.0	CLNG RECOND APP		2
	22.01	EQPT CLEANING.		2
	22.2	SWBD CLNG	÷	2
	22.3	ROTARY SEL BANKS.		2
	22.4	197, 198 SEL	•	2
	22.5	MSSC.		2

22. GENERAL

22.01 This section provides an index and information access system to locate the standard tests applicable to equipment listed in

the preceding table of contents. Test classification and frequency of periodic routine are also provided.

- 22.02 This is the first issuance of the "reformatted ETL" which provides better organization of the various tests. The "reformatted ETLs" replace the ETLs previously provided for this equipment.
- 22.03 Comments on this section should be made by following the instructions in Bell System Practices (BSP), Section 000-010-015.
- 22.04 Routine test information is arranged in the following order from left to right: Section number, issue/addendum, test letter or paragraph number, test title, test class, frequency, and the last space is for a locally assigned job number.
- 22.05 Section 010-300-011 provides Equipment Test List instructions.

NOTICE

Not for use or disclosure outside the Bell System except under written agreement

Printed in U.S.A. Page 1

22.0 CLNG RECOND APP		
22.1 CLNG RECOND APP; EQPT CLEANING		
FOR ALL UNITS		
069-305-301 (3/1) GENERAL CLEANING OFFICE EQPT	MW	*
22.2 CLNG RECOND APP; SWBD CLNG		
FOR ALL UNITS		
069-379-801 (3/0) SWITCHBOARD EQUIPMENT	MW	*
22.3 CLNG RECOND APP; ROTARY SEL BANKS		
SELECT ONLY ONE CATEGORY		
200,206,209,211 TYPE SELECTORS		
069-330-801 (2/0) ROTORS £ BANKS	MW	*
204 TYPE SELECTORS		
069-331-801 (1/0) 204 SEL BANKS £ WIPERS	MW	*
22.4 CLNG RECOND APP; 197, 198 SEL		
SELECT ONLY ONE CATEGORY		
SXS AMA & SXS CAMA TK FDR APPLICATION		
069-501-801 (13/2) BANKS £ WIPERS	MW	6M
SXS TOUCH TONE TK FDR APPLICATION		
069-501-801 13/2) BANKS £ WIPERS	MW	3M
ALL OTHER		
069-501-801 (13/2) BANKS £ WIPERS	MW	12M
22.5 CLNG RECOND APP; MISC		
TROUBLE TESTS		
NORTH ELECT MULTICONTACT RELAYS		
069-307-801 2/0 4.01 (4.01-4.07) PROC FOR CLEANING £ TREATING	TT	
WIRE SPRING TYPE RELAYS		
069-310-803 8/0 CONTACT REPLMT	TT	
BANKS		
069-311-801 3/1 REPAIRING FEEDER BRUSH TIPS	TT	
HEAT COIL & PROT SPG CONTACTS		
069-315-801 2/0 CLEANING	TT	
ROT SWS, ATTS, POTS 6 RHEO STATS		
069-321-801 2/0 CLEANING & TREATING	TT	
REGISTERS		
069-360-801 5/0 CLEANING	TT	
SLIDE WIRE APP		
069-365-801 2/0 2.03 (2.03-2.07) CLEANING	TT	
2.08 (2.08-2.10) LUBRICATING	TT	
PLUGS		
069-380-811 3/0 CLEANING £ POLISHING		

069-380-812 (2/0) CLEANING & POLISHI	NG TT
PLUGS, SWITCHBOARD	
069-380-813 (2/0) CLEANING	TT
CONTACTS, KEY i JACK	
069-386-801 (3/1) CLEANING	TT
JACK FLARES	
069-387-801 (2/0) 3.01 (3.01-3.03) CLEANII	NG TT
JACKS, OPER TEL SET	
069-388-801 (2/0) 4.01 CLEANING	TT
FRAMES, EQUIPMENT (STEP-BY-STEP)	
069-503-801 (5/0) CLEANING	TT
SWITCHES, SEQUENCE	
069-601-801 (5/0) SCRUBBING i SCOURI	NG CAMS TT
INTERRUPTERS, 157-TYPE	
069-601-801 (5/0) SCRUBBING % SCOURI	NG CAMS TT
FRAMES, EQPT (PANEL OFFICES)	
069-603-801 (7/0) CLEANING	TT
PANEL MULT BANK TERMS, ASSOC MULT BRUSHES 6 GUI	DE COMBS
069-605-801 (4/0) CLEANING 6 TREATIN	g TT
TERMINALS, PANEL BANKS	
069-605-803 (4/0) CLEANING & TREATIN	G TT
069-605-803 (4/0) CLEANING & TREATING MULT BRUSHES & GUIDE COMBS	G TT
	g TT TT
MULT BRUSHES & GUIDE COMBS	
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING	TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL	TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATING	TT TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATING BRUSHES, COMMUTATOR	TT TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATING BRUSHES, COMMUTATOR 069-610-801 (10/0) CLEANING 5 TREATING	TT G TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATING BRUSHES, COMMUTATOR 069-610-801 (10/0) CLEANING 5 TREATING FRAMES, EQUIP (X-BAR OFF.)	TT G TT G TT SSED AIR TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATIN BRUSHES, COMMUTATOR 069-610-801 (10/0) CLEANING 5 TREATIN FRAMES, EQUIP (X-BAR OFF.) 069-703-801 (5/0) CLEANING BY COMPRE	TT G TT G TT SSED AIR TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATING BRUSHES, COMMUTATOR 069-610-801 (10/0) CLEANING 5 TREATING FRAMES, EQUIP (X-BAR OFF.) 069-703-801 (5/0) CLEANING BY COMPRE FRAMES, EQUIP (NO. 1 X-BAR 6 X-BAR TANDEM OFF.)	TT G TT G TT SSED AIR TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATING BRUSHES, COMMUTATOR 069-610-801 (10/0) CLEANING 5 TREATING FRAMES, EQUIP (X-BAR OFF.) 069-703-801 (5/0) CLEANING BY COMPRESED FRAMES, EQUIP (NO. 1 X-BAR 6 X-BAR TANDEM OFF.) 069-703-802 (5/0) CLEANING BY COMPRESED FRAMES, EQUIP (NO. 1 X-BAR 6 X-BAR TANDEM OFF.)	TT G TT SSED AIR TT SSED AIR TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATING BRUSHES, COMMUTATOR 069-610-801 (10/0) CLEANING 5 TREATING FRAMES, EQUIP (X-BAR OFF.) 069-703-801 (5/0) CLEANING BY COMPRESE OF	TT G TT SSED AIR TT SSED AIR TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATING BRUSHES, COMMUTATOR 069-610-801 (10/0) CLEANING 5 TREATING FRAMES, EQUIP (X-BAR OFF.) 069-703-801 (5/0) CLEANING BY COMPRES FRAMES, EQUIP (NO. 1 X-BAR 6 X-BAR TANDEM OFF.) 069-703-802 (5/0) CLEANING BY COMPRES FRAMES, EQUIP (NO. 5 X-BAR OFF.) 069-703-803 (4/0) CLEANING BY COMPRES	TT G TT SSED AIR TT SSED AIR TT SSED AIR TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATING BRUSHES, COMMUTATOR 069-610-801 (10/0) CLEANING 5 TREATING FRAMES, EQUIP (X-BAR OFF.) 069-703-801 (5/0) CLEANING BY COMPRESE OF	TT G TT SSED AIR TT SSED AIR TT SSED AIR TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATING BRUSHES, COMMUTATOR 069-610-801 (10/0) CLEANING 5 TREATING FRAMES, EQUIP (X-BAR OFF.) 069-703-801 (5/0) CLEANING BY COMPRES FRAMES, EQUIP (NO. 1 X-BAR 6 X-BAR TANDEM OFF.) 069-703-802 (5/0) CLEANING BY COMPRES FRAMES, EQUIP (NO. 5 X-BAR OFF.) 069-703-803 (4/0) CLEANING BY COMPRES FRAMES, EQUIP (NO. 4A & 4M TOLL SW SYS) 069-703-804 (4/0) CLEANING BY COMPRES	TT G TT SSED AIR TT SSED AIR TT SSED AIR TT SSED AIR TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATING BRUSHES, COMMUTATOR 069-610-801 (10/0) CLEANING 5 TREATING FRAMES, EQUIP (X-BAR OFF.) 069-703-801 (5/0) CLEANING BY COMPRESE OF STREATING FRAMES, EQUIP (NO. 1 X-BAR 6 X-BAR TANDEM OFF.) 069-703-802 (5/0) CLEANING BY COMPRESE OF STREATING OF STREATI	TT G TT SSED AIR TT SSED AIR TT SSED AIR TT SSED AIR TT
MULT BRUSHES & GUIDE COMBS 069-605-803 (4/0) CLEANING COMMUTATORS, PANEL 069-610-801 (10/0) CLEANING & TREATING BRUSHES, COMMUTATOR 069-610-801 (10/0) CLEANING 5 TREATING FRAMES, EQUIP (X-BAR OFF.) 069-703-801 (5/0) CLEANING BY COMPRE FRAMES, EQUIP (NO. 1 X-BAR 6 X-BAR TANDEM OFF.) 069-703-802 (5/0) CLEANING BY COMPRE FRAMES, EQUIP (NO. 5 X-BAR OFF.) 069-703-803 (4/0) CLEANING BY COMPRE FRAMES, EQUIP (NO. 4A & 4M TOLL SW SYS) 069-703-804 (4/0) CLEANING BY COMPRE FRAMES, EQUIP. (NO. 3 X-BAR SYS) 069-703-805 (1/0) CLEANING BY COMPRE	TT G TT G TT SSED AIR TT